

## Instructions for recoding Promatic & Supramatic series 2 handsets with a unique code, transferring new code to receiver & additional handsets

### IMPORTANT

**Before commencing ensure you have access to the garage as changing the code on the handset will stop the operator from working until the new code is transferred.**

This assumes you wish to use the top button of your handset. If not, substitute the instructions for the button of your choice.

### Re-setting the handset with a unique code

- On your remaining handset, slide open the battery compartment.
- You will see a small button to left side of the PCB.
- Press & hold that button with a blunt non-metallic object.
- Press & hold the top button on your handset & the LED on the handset will flash slowly for a maximum of 4 seconds.
- If the small button is released before the slow flashing phase ends, the LED will start to flash more rapidly & the handset will be recoded.
- Now see if the handset opens the door, if it doesn't it's been recoded. If it still opens the door you need to try the above again.

### Transferring the code to the receiver – Promatic

- Locate the "P" button on the underside of the operator, a part of the large transparent button.
- Press the "P" button and release, a red LED behind the transparent button flash.
- Press and hold the top button on your handset until the LED stops flashing.
- Now test by pressing the top button of your handset, this should now operate the door motor.

### Transferring the code to the receiver - Supramatic

- Locate the "PRG" button on the front of the operator
- Press the "PRG" button twice, the LED display will show a "P" then go to a flashing "0"
- Press and hold the "PRG" for Approx. 3 sec until a dot is displayed next to the "0"
- Now press and hold the top button of your handset until the dot is no longer displayed.
- Press the "PRG" twice more to return to normal operating mode.
- Now test by pressing the top button of your handset, this should now operate the door motor.

### Adding additional handsets

If you have additional handsets you will need to transfer the new code to them.

- To do this take the newly coded handset, which is the teaching handset & press & hold the top button.
- Take the learning handset, hold them back-to-back & hold the top button.
- The LED on the learning handset will flash slowly, keep both buttons depressed until this LED starts to flash more rapidly.
- Repeat this for all additional handsets.