

A and C Series Operators Only Instructions for Additional 433MHz Rolling-Code Handsets

IMPORTANT:- If you have more than one Operator in the garage, the power must be switched off the other Operator(s) while programming new hand-sets. Handsets are programmed into the decoder as follows:-

1. Take a registered hand transmitter.
2. Press the buttons for the 3rd and 4th channel simultaneously and let them go again. The decoder starts giving an acoustic signal.
3. Take the new hand-transmitter and press the button you want to use with the device.
4. A long acoustic signal indicates that the hand-transmitter has been registered successfully.

The new decoder chip will register a maximum of 250 hand-transmitters.



N.B. If you experience range problems extend the aerial outside the motor housing.