

## Hormann FCT 3B Keypad

As the programming settings have a set time limit to be completed, we recommend that you read and fully understand the instruction before attempting to program.

### To change the code:

1. Press the "key" button once.
2. Enter the valid code.
3. Press the "key" button once. (If the entry is valid, a long light signal is emitted. If the entry is invalid, 3 short light signals are emitted.)
4. Enter the new 4 digit code.
5. Press the "key" button once, a long light signal is emitted.
6. Enter the new 4 digit code again.
7. Press the "key" button once, a long light signal is emitted and the new code comes into force with immediate effect.

### Programming the keypad from a handset:

For this you will need a working remote for the operator to hand.

1. Enter the valid 4 digit code into the keypad ( Do not press the "key" button just yet )
2. Hold the teaching remote close to the keypad.
3. Press and hold the button on the remote which operates the door.
4. Press and hold the "key" button on the keypad.
5. The LED on the keypad will emit a series of short signals followed by a long signal.
6. Release both buttons and perform a function test on the keypad.